

# DRUM RACK SET-UP

**YELLOW** Cymbal Spring is for RIDE CYMBAL. Felts and Wing Nut are included and may also be used for RIDE CYMBAL.



**RED** Cymbal Spring(s) for CRASH CYMBAL(s). Although felts and Wing Nut are included for Crash Cymbals, we highly recommend using the springs for enhanced feel and to keep Crash Cymbals from rotating while playing.


## HI-HAT CLUTCH

The Hi-Hat "clutch" holds the hh cymbal on to the X-Hat mount.

1. These two "nuts" lock together and compress rubber grommets to hold HH CYMBAL



This "nut" should be tightened securely **FIRST**.



**RUBBER HI-HAT "CUP"**

**NOTE:** You may "compress" Top Cymbal and tighten clutch for loose or tight "feel". Use with Roland TD-20 in VH mode requires adapter.

# Studio Master



**NOTE:** We provide this picture so you can get a basic idea for set-up. You should set-up your drums and position them so that playing is best suited for your style and ability.