

HART DYNAMICS TRIGGER SETTINGS FOR ROLAND TD-3 4/1/05 TE3.2
NOTE: Only highlighted (grey) settings need to be altered from factory settings.

PRODUCT	PAD TYPE	PAD SENS.	THRESHOLD	VEL. CURVE	SCAN TIME	RETRIG	CANCEL	CROSSTALK	MASK TIME	RIM SENS	RIM GAIN
HART PRO SNARE HH TE3.2	125	7	1	Lnr	1.6	3		oFF	8	12	1.4
HART PRO KICK HH TE3.2	KD	9	4	Lnr	2.0	6		oFF	8	NA	NA
HART PRO TOM 8" HH TE3.2	105	7	3	Lnr	1.6	4		70	8	10	1.3
HART PRO TOM 10" HH TE3.2	105	7	3	Lnr	1.6	4		70	8	10	1.3
HART PRO TOM 12" HH TE3.2	125	7	3	Lnr	1.6	4		70	8	12	1.4
HART PRO KICK BL TE3.2	KD	9	4	Lnr	2.0	6		oFF	8	NA	NA
HART PRO TOM 8" BL TE3.2	105	7	3	Lnr	1.6	4		70	8	10	1.3
HART PRO TOM 10" BL TE3.2	105	7	3	Lnr	1.6	4		70	8	10	1.3
HART PRO TOM 12" BL TE3.2	125	7	3	Lnr	1.6	4		70	8	12	1.4
ACUPAD IIST TE3.2	105	7	3	Lnr	1.6	4		70	8	10	1.3
HMK (HAMMER KICK)	KD	9	4	Lnr	2.0	6		oFF	8	NA	NA
ACUPAD BDST TE3.2	KD	9	4	Lnr	2.0	6		oFF	8	NA	NA
9" ECYMBAL II	CY8	9	3	Lnr	2.0	5		45	8	NA	1.1
12" ECYMBAL II	CY8	9	3	Lnr	2.0	5		45	8	NA	1.1
12" ECYMBAL II (choke)	CY8	9	3	Lnr	2.0	5		45	8	NA	1.1
14" ECYMBAL II	CY8	9	3	Lnr	2.0	5		45	8	NA	1.1
14" ECYMBAL II (choke)	CY8	9	3	Lnr	2.0	5		45	8	NA	1.1
16" RIDE ECYMBAL II	CY8	9	3	Lnr	2.0	5		45	8	NA	1.1
12" HH ECYMBAL II	105	7	1	Lnr	1.6	2		70	8	10	1.3
12" ECYMBAL II CHINA	CY8	9	3	Lnr	2.0	5		45	8	NA	1.1
14" ECYMBAL II CHINA	CY8	9	3	Lnr	2.0	5		45	8	NA	1.1
9" ECYMBAL S	CY8	9	3	Lnr	2.0	5		45	8	NA	1.1
12" ECYMBAL S	CY8	9	3	Lnr	2.0	5		45	8	NA	1.1
12" ECYMBAL S /CHOKE	CY8	9	3	Lnr	2.0	5		45	8	NA	1.1
14" ECYMBAL S	CY8	9	3	Lnr	2.0	5		45	8	NA	1.1
14" ECYMBAL S /CHOKE	CY8	9	3	Lnr	2.0	5		45	8	NA	1.1
12" ECYMBAL S HH	105	7	1	Lnr	1.6	2		70	8	10	1.3
16" ECYMBAL S RIDE	CY8	9	3	Lnr	2.0	5		45	8	NA	1.1
12" ECYMBAL S CHINA	CY8	9	3	Lnr	2.0	5		45	8	NA	1.1
14" ECYMBAL S CHINA	CY8	9	3	Lnr	2.0	5		45	8	NA	1.1
HM6MT (MULTIPAD)	X	X	X	X	X	X		X	X	X	X
HM1-C (HAMMER PAD)	80r	8	1	Lnr	1.6	1		70	4	10	1.1

* Not recommended for use with HM6MT - Multipad